

# ASSEMBLY INSTRUCTIONS

## Poly Windvane Feeder WVP-6000 (28112013)

**Hardware Pkg.  
28900108**

### THANK YOU FOR PURCHASING THIS PRODUCT

For questions about this product, or parts inquiries, please contact our Customer Service Center listed

**Before beginning, read instructions thoroughly and inspect parts listing to insure that all parts have been included. During the assembly process, refer to illustration for clarity.**

1. Slide four Legs (1) into Pivot Base Weldment (5) making sure tie down holes are up and fasten with four 1/2" x 1-1/4" Hex Bolts (6).
2. Attach Grease Fitting (11) to Support Frame Weldment (3) by pounding it in with a hammer.
3. Attach Support Frame Weldment (1) to Bottom of Poly Feeder (2) by inserting four 3/8" x 1" stainless steel Hex Head Bolts (7) and 3/8" stainless steel Fender Washers (10) down through Feeder and fasten under Frame with four 3/8" Lock Washers (9) and 3/8" Hex Nuts (8). NOTE: Make sure vertical tube on Support Frame is toward the front of the Feeder.
4. Slide Support Frame Weldment (3) over vertical leg of Pivot Base Weldment (5). Tighten 3/8" x 1" Hex Bolt (4) just enough to catch ring on Base so Feeder will pivot freely.

### PARTS LISTING

<u>ITEM</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>	<u>QTY</u>
1	Tube, Leg Short	28600803	4
2	Feeder, Poly w/Holes	28712038	1
•	Parts Package F/WVP6000	----	1
3	<b>Support Frame Weldment</b>	28400203	1
4	* 3/8" - 16 x 1" Hex Bolt z.p.	----	1
5	<b>Pivot Base Weldment</b>	282400213	1
6	*1/2" - 13 x 1-1/4" Hex Bolt z.p.	----	4
•	<b>Hardware Package</b>	----	1
7	*3/8" - 16 x 1" Hex Bolt s.s.	----	4
8	*3/8" - 16 Hex Nut z.p.	----	4
9	*3/8" Lock Washer z.p.	----	4
10	*3/8" Fender Washer z.p.	----	4
11	*Greased Fitting	----	1

\*Standard Hardware Item. May be purchased locally. • Not Illustrated.

**Behlen  
COUNTRY**

### CUSTOMER SERVICE CENTER

PO Box 569  
Columbus, NE  
68602-0569

Ph: 1-800-447-2751  
Fax: (402) 563-7447

# ASSEMBLY INSTRUCTIONS

